

INSTALLATION and REMOVAL INSTRUCTIONS

SHRINK DISCS MAV 2008 – MAV 2108 – MAV 2208



GENERAL RECOMMENDATIONS and WARNINGS

- Before installing or handling this product, read instructions carefully and completely. Due to possible danger to persons or machinery resulting from improper use of this product, it is very important to follow correct procedures. Proper installation, maintenance and operation procedures must be observed. All instructions included in this manual must be followed carefully. Handling, installation and removal of this product must be done by skilled personnel, familiar with the product, the application and all hazards involved.
- Suitable safety devices should be provided and applicable safety rules should be observed as specified in safety codes. Those are neither the responsibility of MAV S.p.A., nor are provided by MAV S.p.A.
- Contravention of install and safety instructions will void all claims under warranty.
- During storage or handling operations, use only tested and approved handling and/or lifting tools. Make always sure that components of the Shrink Disc are secured against slipping, falling or rolling.
- Prior to initiating installation or removal procedures, check to ensure that no loads are acting on Shrink Disc, shaft or any connected component. Motor and drive train must be switched off and secured against accidental activation.

GENERAL INFORMATION

- Shrink Discs MAV 2008 – MAV 2108 – MAV 2208 are external locking devices, which provide a rigid, zero-backlash, frictional keyless connection between an outer hollow shaft (hub) and an inner shaft. Shrink Discs are installed onto the outer diameter of the hub, which is mounted onto the shaft.
Shrink Discs are suited for transmitting torque, axial load and bending moment, separately or in combination. Applied loads are transmitted via pressure and friction between the fitting surfaces of hub and shaft. In tightened condition, Shrink Discs exert high radial pressure on hub and shaft.

- **Shrink Discs are supplied ready for installation.** However, it is necessary to **remove the spacers** that may have been used for shipping purpose prior to initiating the installation. They are composed of (fig. 1):

- one inner ring (slotted)
- one front outer ring with clearance holes, zinc plated
- one rear outer ring with threaded holes, zinc plated
- one set of hexagon head cap screws ISO 4014/4017 grade 10.9 (< M6 grade 8.8)
- one rubber O-Ring between outer rings (as protection from dust and dirt, from size d = 140)

Shrink Discs supplied in **SPLIT** version are composed of:

- two split inner rings (slotted)
- one front outer ring with clearance holes, zinc plated
- one rear outer ring with threaded holes, zinc plated
- two rubber O-Rings (as protection from dust and dirt, from size d = 140)

Bolting hardware is supplied only upon request

Shrink Discs supplied in **HALF HC and HT** versions are composed of:

- one split inner ring (slotted)
- one front outer ring with clearance holes (HC) or rear outer ring with threaded holes (HT), zinc plated
- one rubber O-Ring (as protection from dust and dirt, from size d = 140)

Bolting hardware is supplied only upon request

- Lubrication.
 - ! ○ **Screws (under-head and threads): greased at factory with solid paste DOW CORNING MOLYKOTE® BR 2 Plus. Don't remove the lubricant.**
 - ! ○ **Conical surfaces: greased at factory with solid paste DOW CORNING MOLYKOTE® G-Rapid Plus. Don't remove the lubricant.**
 - ! ○ **Hub ID and shaft OD: lubricant-free and dry.**
 - Hub OD: lubrication with oil or grease is recommended for ease of installation.
- Recommended tolerances. Functional values in the catalog are based on values specified below. Any deviation requires new rating of functional values.
 - Hub OD: h8 or f7
 - Hub ID and shaft: see table

Shaft dia.		ISO Tolerances	Max diam. clearance
above	up to		mm
6	10	H6/j6	0,011
10	18		0,014
18	30		0,017
30	50	H6/h6	0,032
50	80	H6/g6	0,048
80	120	H7/g6	0,069
120	180		0,079
180	250		0,090
250	315		0,101
315	400		0,111
400	500		0,123

- Recommended hub / shaft surface finish: $0.8 \leq Ra \leq 3.2 \mu\text{m}$
- Tightening torque. Functional values in the catalog are based on specified tightening torque (Ma). Tightening torque may be reduced up to $0.6 \cdot Ma$ (max reduction by 40%). Reduction of tightening torque requires new rating of functional values.
- After installation is completed, it is usually not necessary to re-check tightening torque after equipment has been in operation. However, loosening of the screws may occur in connections subject to severe operating conditions. In these instances, periodic check of screws tightening torque is recommended.








Fig. 1. Composition.

INSTALLATION

SAFETY NOTICE

Prior to initiating the installation procedure, check to ensure that no loads are acting on Shrink Disc, shaft or any connected component. Motor and drive train must be switched off and secured against accidental activation.

-  Shrink Disc MAV 2008 – MAV 2108 – MAV 2208 are supplied ready for installation. However, it is necessary to remove the spacers that may have been used for shipping purpose prior to initiating the installation.
-  Do not remove the grease from screws and conical surfaces (fig. 2).
-  Do not remove the O-Ring.
-  Never tighten the screws prior to mounting the Shrink Disc onto the shaft, as inner ring and/or hub might remain permanently contracted even at relatively low tightening torques.

1. Clean hub OD and Shrink Disc bore. For ease of installation, lightly lubricate hub OD before assembling Shrink Disc onto hub (fig. 2).
2. Carefully solvent clean and dry shaft and hub bore from any lubricant (fig. 2) prior to mounting hub onto shaft. This step is critical, as any lubricant on the shaft/hub bore interface will greatly reduce the capacity of the Shrink Disc connection.
3. Move the Shrink Disc onto the hub, then move the hub onto the shaft until the required position is achieved. **The shaft must support completely the tolerated section of hub bore (fig. 2). Hand-tighten three or four evenly spaced screws (fig. 3) and make sure that outer rings are parallel;** then hand-tighten remaining screws. At the end of this stage, a light connection is achieved. Hub will not move axially respect to shaft during next tightening steps.




Fig. 2. Lubrication.




Fig. 3. Pre-tightening

4. Use a torque wrench set approx. 5% higher than specified tightening torque (Ma), or reduced within admissible value. **Progressively tighten the screws in either a clockwise or counterclockwise sequence, using approx. ¼ turns for several passes** until ¼ turns can no longer be achieved (fig. 4).




Fig. 4. Example of tightening pattern.

5. Still apply overtorque for a few more passes. This is required to compensate for a system-related relaxation of the screws since tightening of a given screw will always relax adjacent screws. Without overtorquing, a very large number of passes would be needed to reach the specified tightening torque.
 6. Reset the torque wrench to specified tightening torque (M_a), or reduced within admissible value, and check all screws in either a clockwise or counterclockwise sequence. The installation is completed as long as no screw can be turned further, otherwise repeat step 5.
- !** Once the screws are tightened, **check the parallelism of outer rings**. The max deviation of the distance between outer rings around the circumference shall be within 0,35% of the outer diameter (fig. 5). A larger error may cause a loss of pressure and, as a consequence, reduced performances.




Fig. 5. Parallelism of outer rings.

REMOVAL

SAFETY NOTICE

Prior to initiating the removal procedure, check to ensure that no loads are acting on Shrink Disc, shaft or any connected component. Motor and drive train must be switched off and secured against accidental activation.

SAFETY NOTICE

DO NOT completely remove the screws before outer rings are disengaged. Sudden separation of the rings may occur and involve high separation forces that may result in permanent injury or death. Be certain that the rings are disengaged before completely removing the screws.

1. **Progressively loosen all screws in either a clockwise or counterclockwise sequence, using approx. ½ turns for several passes** until the outer rings have released from the inner ring (self-releasing tapers).
2. Remove the hub from the shaft, then remove the Shrink Disc from the hub.

REUSE of USED SHRINK DISCS

1. **Disassemble, thoroughly clean and inspect all parts** of the Shrink Disc. Permanent deformations, ovalizations, dents, corroded areas, are not admitted. In case of doubts, contact MAV S.p.A. for advice.
2. **Re-lubricate** the Shrink Disc with the following products.
 - **DOW CORNING MOLYKOTE® BR 2 Plus** on screws under-head and threads.
 - **DOW CORNING MOLYKOTE® G-Rapid Plus** on conical surfaces.
3. Replace the O-Ring by glueing together the ends of a cord of **aerstop®** EPDM + SBR rubber code SE34.
4. Re-assemble all parts as originally supplied.