

## GTP80 AVAILABLE CODES

Code	Inp.	Out.	Analogic Inp.	Analogic Out.
<b>GTP_80/ST</b>	16 PNP	16 from 0,5A	no	2 from +/- 10V 2 from 0..10V 2 PWM
<b>GTP_80/SPT</b>	16 PNP	16 from 0,5A	4 for PT100 (0...300) 4 from 0..10V	2 from +/- 10V 2 from 0..10V 2 PWM
<b>GTP_80/SCT</b>	16 PNP	16 from 0,5A	8 from 0..20 mA	2 from +/- 10V 2 from 0..10V 2 PWM
<b>GTP_80/SVT</b>	16 PNP	16 from 0,5A	8 from 0..10V	2 from +/- 10V 2 from 0..10V 2 PWM
<b>GTP_80/SJT</b>	16 PNP	16 from 0,5A	4 for TMC J (0..300) 4 from 0..10V	2 from +/- 10V 2 from 0..10V 2 PWM
<b>GTP_80/SKT</b>	16PNP	16 from 0,5A	4 for TMC K (0..400) 4 from 0..10V	2 from +/- 10V 2 from 0..10V 2 PWM

### **Other options:**

- **/ETH: Ethernet** option with Web Server function.